Key to Fig 13:1 1 Turn indicator front righthand 2 Headlight righthand 3 Long-range headlight righthand 4 Parking light righthand 5 Parking light lefthand 6 Long-range headlight lefthand 7 Headlight lefthand 8 Turn indicator front lefthand 9 Dip relay 10 Dipswitch with headlight flasher 11 Light switch 12 Engine compartment light switch 13 Engine compartment light 14 Horn righthand 15 Horn lefthand 16 Horn relay 17 Horn ring 18 Fuse box 21 Coil 22 Distributor 23 Starter 24 Battery 25 Reversing light switch 26 Stoplight switch 27 Heated rear window 19 Alternator 20 Voltage regulator 28 Screen wiper motor 29 Screen wiper switch 30 Selector gate light 31 Screen washer pump 32 Delay relay 33 Heater switch 34 Heater blower switch 36 Flasher unit 37 Turn indicator/parking light/screen washer switch 38 Oil pressure contact 39 Water temperature thermocouple 35 Cigar lighter motor 40 Plug-in connector 41 Electric window lift front righthand 42 Terminal board 43 Front window lift switch 44 Terminal board 45 Electrical window lift front 46 Electric window lift rear righthand 47 Terminal board 48 Rear righthand window lift switch 49 Rear lefthand window lift switch lefthand 50 Terminal board 51 Electric window lift rear lefthand 52 Fuel gauge tank contact 53 Interior light 54 Door switch righthand 55 Door switch lefthand 56 Luggage compartment 57 Luggage compartment light 58 Heated rear window 59 Plug-in connector 60 Turn indicator rear righthand 61 Rear light righthand 62 Stoplight light switch righthand 63 Reversing light righthand 64 Number plate lights 65 Reversing light lefthand 66 Stoplight lefthand 67 Rear light lefthand 68 Turn indicator rear 69 Choke cable contact 70 Ignition/starter switch 71 Radio 72 Separate fuse 73 Combined instrument 74 Revolution counter lefthand 75 Speedometer 76 Clock 77 Rear loudspeaker

Instruments: a Instrument lighting b Cooling water thermometer c Fuel gauge d Oil pressure telltale e Choke and fuel reverse telltale f Battery charge telltale g Main beam telltale h Turn indicator telltale

Ignition/starter switch, Key positions: I Lock II Garage III Fahrt (Drive) IV Start

Fuses: 1-2-3-4-5-6=8 Amp 7-8=25 Amp

Firing order: 1-3-4-2

Cable coding: .75 sq mm cross-section Colour: BL Blue BR Brown GE Yellow GN Green SW Black WS White Items 27–28–59–71–72–77=Special equipment Item 30 only when automatic gearbox fitted X=When manual gearbox is fitted,